



# Fujifilm FinePix S2980 LCD Screen Replacement

This guide will show you how replace a cracked or malfunctioning LCD screen.

Written By: Megan Merlo





## TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — LCD Screen



- Use a PH0 screwdriver to remove four screws on the right side, three screws on the bottom, and four on the left side to take off the rear plate.

## Step 2



- Remove the three screws holding the LCD screen in place.
- Replace with new screen.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 07:53:55 AM.